


SCANSONIC USB100



USER MANUAL (ENGLISH) -----	P1-P9
MANUEL D'UTILISATION (FRANÇAIS) -----	P10-P18
Schnellbednugscanleitung (DEUTSCH) -----	P19-P27
Snel Begin Het Handboek van de eigneaar (DUTCH) -----	P28-P36
Manual de inicio rápido del usuario (ESPAÑOL) -----	P37-P45

IMPORTANT SAFETY INSTRUCTIONS

1. Read Instructions – All the safety and operating instructions should be read before this product is operated.
2. Retain Instructions – The safety and operating instructions should be retained for future reference.
3. Heed Warnings – All warnings on the appliance and in the operating instructions should be adhered to.
4. Follow Instructions – All operating and use instructions should be followed.
5. Water and Moisture – The appliance should not be used near water - for example, near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool, and the like.
6. Carts and Stands – The appliance should be used only with a cart or stand that is recommended by the manufacturer. An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.
7. Wall or Ceiling Mounting – The product should not be mounted to a wall or ceiling.
8. Heat – The appliance should be situated away from heat sources such as radiators, heat registers, stoves, or other appliances (including amplifiers) that produce heat.
9. Power Sources – This product should be operated only from the type of power source indicated on the rating label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company. For products intended to operate from battery power, or other sources, refer the operating instructions.
10. Grounding or Polarization – This product may be equipped with a polarized alternation-current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.
11. Power-Cord Protection—Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to the cord in correspondence of plugs, convenience receptacles, and the point where they exit from the appliance.
12. Cleaning - The appliance should be cleaned only as recommended by the manufacturer. Clean by wiping with a cloth slightly damp with water. Avoid getting water inside the appliance.
13. For AC line powered units - Before returning repaired unit to user, use an ohm-meter to measure from both AC plug blades to all exposed metallic parts. The resistance should be more than 100,000 ohms.
14. Non-use Periods—The power cord of the appliance should be unplugged from the outlet when left unused for a long period of time.
15. Object and Liquid Entry—Care should be taken so that objects do not fall and liquids are not spilled into the enclosure through openings.
16. Damage Requiring Service—The appliance should be serviced by qualified service personnel when:
 - A. The power-supply cord or the plug has been damaged; or
 - B. Objects have fallen, or liquid has been spilled into the appliance; or
 - C. The appliance has been exposed to rain; or
 - D. The appliance does not appear to operate normally or exhibits a marked change in performance; or
 - E. The appliance has been dropped, or the enclosure damaged.
17. Servicing—The user should not attempt any service to the appliance beyond that described in the operating instructions. All other servicing should be referred to qualified service personnel.
18. Ventilation – Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from overheating, and these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is the manufacturer's instructions have been adhered to.
19. Attachments – do not use attachments not recommended by the product manufacturer as they may cause hazards.
20. Accessories – Do not place this product on an unstable cart, stand, tripod, bracket, or table. The product may fall, causing serious injury to a child or adult, and serious damage to the product. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the product. Any mounting of the product should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.
21. Lightning – For added protection for this product during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power-line surges.
22. Replacement Parts – When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.
23. Safety Check – Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition





CAUTION
DO NOT OPEN
RISK OF ELECTRIC SHOCK



CAUTION: To reduce the risk of electric shock, do not remove any cover. No user-serviceable parts inside. Refer servicing to qualified service personnel only.



The lightning flash with arrowhead symbol within the equilateral triangle is intended to alert the user to the presence of un-insulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock.



The exclamation point within the equilateral triangle is intended to alert the user to the presence of important operation and maintenance (servicing) instructions in the literature accompanying this appliance.

To prevent electric shock, do not use this polarized plug with an extension cord, receptacle or other outlet unless the blades can be fully inserted to prevent blade exposure.


LINE VOLTAGE SELECTION

Just for dual voltage mode only! Because power supplies vary from location to location we have incorporated a selectable power supply.

The desired voltage may be set with the VOLTAGE SELECTOR switch located under the platter. (use a flat head screw driver).

Do not force the VOLTAGE SELECTOR switch as this may cause damage.

If the VOLTAGE SELECTOR switch does not move smoothly, please contact a qualified service technician.



BEFORE USE

Check for the following parts included in the package with the main unit:


Platter	Cartridge	DISC	45 rpm adaptor
Slipmat	USB cable	RCA cable	Instruction manual
Headshell	Counter weight	Dust cover	

Very Important!

Do not forget to attach rubber belt to motor for correct operation. After placing the Turntable Platter onto the turntable through the Center Spindle, move one of the large windows on the Platter to top right corner. Attach rubber belt around motor. (Rubber belt is already attached to the underside of the Turntable Platter.)

Notes:

1. Do not connect the AC power plug before assembly has been completed.
2. Before turning the power on, make sure once again all the connections and power voltage settings are correct. Always turn off the power when connecting or disconnecting.
3. Read this manual carefully before using the unit. Be sure to store the manual in a safe place for future reference.



ASSEMBLY

1. Remove the main unit with the packing from the box and remove the packing.
2. Set the 45-rpm adaptor on the main unit.
3. Set the turntable platter onto the center spindle.
4. Set the slip mat on the platter.
5. Installation of cartridge:

When installing a cartridge, refer to the operating instructions of that cartridge.

During installation, attach the stylus protector to guard the stylus tip from damage.

- (a) Connect the lead wires to the cartridge terminals. The terminals of most cartridges are color-coded. Connect each lead wire to the terminal of the same color.

White (L+)..... Left channel+

Blue (L-)Left channel-

Red (R+) Right channel+

Green(R-) Right channel-

- (b) Install the cartridge to the headshell and tighten it with screws provided with the cartridge.

6. Insert the headshell into the front end of the tonearm, and then turn the lock nut counterclockwise with the headshell firmly held horizontally.
7. Slide counterweight onto tonearm. Twist it lightly and it will screw onto the rear shaft of the tonearm.
8. Adjustment of horizontal "zero" balance and stylus pressure:
 - (a) Remove the stylus protector from the headshell; do not touch the stylus tip during the adjustment.
 - (b) Set the cueing lever to the lowered position.
 - (c) Release the tonearm clamp and lift the tonearm from the armrest to free it.
 - (d) Rotate the counterweight until the tonearm is approximately balanced horizontally (floats freely).
 - (e) Refasten the tonearm with the tonearm clamp.
 - (f) Hold the counterweight stationary with one hand and rotate only the stylus-pressure ring to bring the number "0" of the ring into alignment with the centerline on the tonearm rear shaft.
 - (g) Rotate the counterweight including the stylus-pressure ring counterclockwise until the scale shows the value corresponding to the pressure of the stylus used. Should you use a separate Stylus, please follow the manufacturer's instructions.
9. Set the anti-skating control knob to the same value as the stylus pressure.
10. Install the dust cover to the main unit's dust cover hinges.

PLACEMENT

- Do not place the unit in a location where it will be exposed to direct sunlight or near a heating appliance.
- Do not place the unit in a location where there is high humidity or a lot of dust.
- Cartridge may pick up slight sound pressures or vibrations of the speakers coming along the floor or through the air resulting in feedback or "howling" sound. Find a location that is very stable and vibration free.
- The legs have functions for adjusting the height of the unit itself. Adjust the legs to stabilize the main body horizontally.

CONNECTIONS

Before connecting the unit it is advised that you also consult your current equipment instruction manual.

IMPORTANT : Be sure to turn off the equipment before you make changes to the different connections.

1. Connect the power cord to an AC outlet.
2. Connect the RCA cable to the PHONO input of your AMPLIFIER.


Output terminals	Amplifier (Receiver)
L (White)	L Channel
R (Red)	R Channel

NOTE:

If this connection is not made or is loose, a power source "HUM" will result.

You can also use a line input by setting the phono / line switch at the rear of the turntable to line.

3. Connect PC via USB cord.



OPERATIONS

1. Turn the On/Off Switch clockwise to turn on the power, the speed indicator and the strobe-illuminator, which is located beneath the On/Off switch, will light up.
2. Place a record on the slip mat. When playing a 45-rpm record with a large center hole, place the 45-rpm adapter on the center spindle.
3. Set the speed to match the record.
4. Remove the stylus protector from the Headshell Stylus and then release the Tonearm clamp.
5. Set the cueing lever to the up position.
6. Press the Start/Stop Button; the turntable platter will start to rotate.
7. Move the tonearm over the desired groove.
8. Set the cueing lever to the down position, the tonearm will descend slowly onto the record and begin playing.
9. When play is finished, raise the cueing lever, move the tonearm onto the Tonearm clamp.
10. Press the Start/Stop Button to stop the platter from rotating. Turn the On/Off Switch counterclockwise to turn off the power.

* SUSPEND PLAY

Set the cueing lever to "UP" position during play, the stylus tip of the cartridge will be lifted from the record.

CHANGING THE SPEED

As long as the pitch control is in center "detent" click position, the turntable is operated at selected speed.

The speed can be increased or decreased by 10% by the pitch control.

An incorrect adjustment done on purpose can also be used to have the turntable rotate extremely slow or fast.

The strobe dots at the edge of the turntable are used for speed monitoring.

MAINTENANCE


Clean the stylus periodically with a soft brush to prevent the accumulation of dust.

When sound becomes distorted or noisy, check the stylus. If the stylus is worn out, replace it with a new one.

From time to time, the dust cover and turntable cabinet should be wiped down with a soft, rdy cloth.

Volatile materials should not be used, such as: alcohol, thinner, benzine etc. They may remove the paint or damage the luster.

CONTROLS OVERVIEW



1. 45-rpm Adaptor

This adaptor allows you to play standard 7" EP vinyl records with large center holes. Place the adaptor on the CENTER SPINDLE 7" records.

2. Turntable Platter

This platter connects directly to the center spindle. The platter and center spindle holds a vinyl record perfectly center. The platter also spins the record at a consistent speed.

3. Strobe Indicators

The PLATTER has four rows of indicators. These indicators are used to visually detail various stages of pitch. The indicators are illuminated by the STROBE INDICATOR PILOT LAMP. Each row may appear to stand still at different pitch levels.

Note: The use of heavy fluorescent lighting directly above the turntable will defeat the STROBE LAMP PILOT LAMP affect indicator accuracy.

4. Center Spindle

This spindle holds the turntable PLATTER records stable and centered.

5. Strobe Indicators Pilot Lamp

This is lamp specially designed to pulse a beam of light at the STROBE INDICATORS on the turntable PLATTER. This will give the illusion that indicators are not spinning at certain speeds.

6. Power Switch

This is a rotary power switch. To turn main power on turn the switch in a clockwise direction. To turn main power off turn the switch in counterclockwise direction.

7. Start/Stop Button

This over sized push button controls platter motion. When the unit is turned on the platter will not automatically begin to spin. Pressing the button once will engage the high torque motor and spin the platter, pressing this again will stop the platter.

8. Headshell

The included HEADSHELL is used to connect your stylus with the tonearm.

9. Headshell Locking Nut

After attaching the headshell to the tonearm, this locking nut will securely hold the headshell to the tonearm.

10. S-Shaped Tonearm

The tonearm is the mechanism that holds the HEADSHELL and stylus allowing it to glide across a record.

11. 33-RPM Speed Select Button

Engaging this button will rotate the platter at 33 revolutions per a minute (RPMs). A function LED will glow when this function is activated.

12. 45- RPM Speed Select Button

Engaging this button will rotate the platter at 45 RPMs. A function LED will glow when this function is activated.

13. Pitch Control Slider

This slider is used to adjust the playback pitch percentage (platter speed).

14. Tonearm Lever

This lever is used to safely elevates the tonearm above a record surface without endangering a records surface.

15. Arm Rest Clamp and Rest

Use this rest to safely hold the tonearm in position during non-use and transportation.

16. Anti-skate Knob

The anti-skate applies inward force to the tonearm to prevent outward skipping across the record due to the centrifugal force cause by platter rotation. The anti-skate value should be equally to that of the stylus counterweight pressure.

17. Stylus-Pressure Ring

* The counterweight scale must face toward the DJ.

18. Extra Stylus Holder

This cut out has been designed to safely store an extra stylus headshell.

19. Counterweight

Use the counterweight to balance the tonearm and to adjust the stylus pressure.

20. Hinge For Dust Cover

21. USB Socket (USB cable limit within 3m)

After connecting the Turntable to the computer via USB, you can record your vinyl to your hard disk using the included Audacity software.

22. Phono/Line Selector

This switch is used to change the mode of phono output or line output

23. RCA output Jacks

The output is able to switch to PHONO output or LINE output. For example: These jacks are used to send a low voltage "phono" level output signal to a mixers "phono" input jacks. Turntables should be connected to "Phono" inputs on a mixer. The red colored RCA jack represents the right channel input and the white represents the left channel input.


AUDACITY SOFTWARE OVERVIEW

Audacity is free software, licensed under the GNU General Public License (GPL). More information as well as open source code can be found on the CD included or on the web at <http://audacity.sourceforge.net/>


* Please ensure you have installed the software before starting.

Setting up your PC to work with Audacity

1. Connect an input source to the unit.
2. Connect the USB lead to your computer.
3. Install the Audacity recording software.
4. Open the Audacity program.
5. Select Preference from the Edit tab in the Audacity Menu.



6. Select Devices at the top left.
Under, Interface, Host, select **Windows DirectSound**.
Under Playback, Device, select **your internal sound card**.
Under Recording, Device, select **USB Audio CODEC**.
Under Recording, Channels, select **2 (Stereo)**.




Recording Albums with Audacity

1. Saving a project

Audacity writes all the changed and recorded audio to a directory called **Projectname_data**, which is located right where you saved the project file itself.

Thus, select **Save project as** from your Audacity File tab and choose a location and filename for your project. Please note that when you startup Audacity fresh, only the "Save As..." menu option is available.




2. How to record

Set your USB turntable up to play the song or album you want to record.

Click on the red Record button  to begin recording.

Lower tone arm on USB turntable onto album and track you want to record.

Click on the blue Pause button  to pause the recording. Press it again to continue.

Click on the yellow Stop button. 

That's it. You can now play around with your recording and explore the editing capabilities of Audacity. Remember that you can use the Undo function almost without limits while the project is open.

NOTE: CD's cannot be burned directly from the Audacity application. Other CD burning applications should be used.

SPECIFICATION

GENERAL

Model:	USB100
	Professional Belt Drive USB Turntable
Dimensions:	450(W) x 350(D) x145 (H) mm
Weight:	4.0Kgs
Power supply:	Dual Voltage: AC 115V~60Hz/230V~50Hz, User Selectable
Power consumption:	8W
Standard test condition:	Ambient Temperature: 23 +/- 2 degC Relative Humidity: 65% +/- 5%

NOTE: Measurements can be carried out between 5 degC to 35 degC and 45% to 85% relative humidity.

TURNTABLE SECTION:

Type	2-speed full manual
Motor	DC motor
Driving Method	Belt drive
Turntable Platter	332mm dia. Plastic
Speeds	33 ¹ / ₃ and 45rpm
Wow and Flutter	Less than 0.25% WRMS (JIS WTD) with 33 ¹ / ₃ rpm
S/N Ratio	More than 50dB (DIN-B)
Pitch Controls	+/- 10%
Starting Time	Less than 1 sec with 33 ¹ / ₃
Braking Time	Less than 1 sec. with 33 ¹ / ₃
Time for Speed Change	Less than 1 sec. from 33 ¹ / ₃ to 45 rpm Less than 1 sec. from 45 to 33 ¹ / ₃ rpm
Speed tolerance at pitch=0	Within +3%, -2%
USB Function	USB rec. Function A/D, D/A 16BIT 44.1KHz or 48KHz USB SELECTABLE Computer interface USB 1.1 compliant, WINDOWS XP or MAC OSX

TONARM SECTION:

Type	Static balanced S-shaped tonearm with detachable headshell
Effective Arm Length	220 mm
Tracking Error Angle	Less than 3 degree
Applicable Cartridge Weight	3.5-8.5g
Anti-skating Range	0-4g
Phono Output Level	1.5~3.6 mV at 1KHz 5cm/sec (HP-4005)
Line Output Level	90~216mV at 1KHz 5cm/sec (HP-4005)
Frequency Response	20Hz-20KHz
Channel Separation	More than 15dB
Channel Balance	Within 2.5dB at 1KHz
Needle Pressure range	3~4g
High of cue(first track)	8~10.5mm
Descend of cue	1~3sec

EQ AMP

Output	150mV +/-4dB (IN: 2.5 mV 1KHz)
RIAA	20Hz~20KHz +1/-3dB (IN: 1.5 mV 1KHz)